


## Setting up PDT Terminal

**\*make sure you have charged your PDT adequately before setting it up**

### 1. Calibrate Screen


- This will be displayed automatically for the first time you start up the PDT
- Click on the crosses on the screen as shown in the diagram to the right using the pen which is situated on the top right of the PDT




### 2. Setup Time & Date

- Double click on the time located on the bottom right of the screen
- Select the correct time zone for your State and click on the Apply button
- Then adjust the time and date correctly and click on the Apply button

### 3. Setup Wireless Connection

- Double click on the wireless icon on the bottom of the screen  it looks like a fork and might have a red cross over it
- Scroll to the wireless information tab using the arrows at the top
- Double click on either AMCR or DLINK wireless signal if you do not see them you might have to move closer to the wireless router
- Un tick the check box which says “This key is given to me automatically”
- Use the on screen keyboard by clicking on the icon next to the time and click on keyboard.
- Select the CAPS button and type in the WEP Key field AB 13 times or 26 characters as shown below
- ABABABABABABABABABABABABABABAB
- Then click the OK button on the top right screen
- The red cross will be removed from the wireless fork after 15 seconds to show that it has connected to the wireless network

### 4. Setup Portal Login


- Click on the start button on the bottom left corner 
- Click on Programs
- Click on Internet Explorer
- Click on Tools or View
- Click on Internet Options
- In the Home page field type in the following address using the on screen keyboard situated near the time

E.g. **hair.eposportal.com/Login.php?site=1000**

**\*Please note words in bold might be different for your company please check your Portal address**

**to confirm this as well as your site number. If you are unsure please contact AMC Support**

5. Setup Scanner

- If your scanner does not scan
- Click on the start button on the bottom left corner 
- Click on Programs
- Click on Scanner
- Click on the scanner program

6. Reset PDT

- To Reset the PDT turn it over to the back and use the pen to click on the small black button which has Reset next to it. Hold it down for 5-10 seconds

**Please always keep your PDT off and charged when you are not using it**